



perform[®] advanced alcohol EP

Microbial filtrated, alcohol-based ready to use solution for disinfecting surfaces in cleanroom



- Fast, effective and residue free
- Microbial filtrated (0,2µm)
- Suitable for cleanrooms grade C/D
- Ready to use
- Color and perfume free
- Efficacy tested according to European norms (EN)

Application areas

Disinfection of surfaces and equipment/devices in cleanroom areas and other areas with strict hygienic requirements.

Composition

100g contain: 25g Ethanol (94%), 35g Propan-1-ol.

Microbiological efficacy:

Efficacy:	Concentration:	Contact time:
Bactericidal, EN1276, EN13697	Ready-to-use	1 minute
Fungicidal, EN1650, EN13697		1 minute
Enveloped viruses (incl. HIV, HBV and HCV), in accordance with DVV (German registered association for combating viral diseases) RKI guideline		30 sec.

Chemical-physical data:

Density	: appr. 0,89 g/cm ³ / 20°C
Color	: Colorless
pH value	: appr. 7 / 20°C (undiluted)
Flash point	: 27°C / Method: DIN 51755 Part 1
Form	: Liquid

Special advice

Use disinfectants safely. Always read the label and product information before use.

Instructions for use

Apply perform[®] advanced alcohol EP undiluted to objects and surfaces and allow to take effect. Ensure complete wetting. The product dries off quickly. perform[®] advanced alcohol EP can be used for glove disinfection. Maximum application rate 50 ml/m². Do not use to treat surfaces that are particularly sensitive to alcohol, such as acrylic glass.

Art.-no.:	PU:
RREIN-PER-ADEP	10 x 1 l bottles
RREIN-PER-ADEP(10)	1 x 10 l canister

hans j. michael gmbh

Gewerbegebiet Hart 11, D-71554 Weissach i.T., Phone: 0049-7191-9105-0, Fax: 0049-7191-9105-19
e-mail: office@hjm-reinraum.de, website: <http://www.cleanroom-hjm.com>